


# C系列-爆炸圖


三點式組合



Index NO:	Part NO:	Description	Index NO:	Part NO:	Description	Index NO:	Part NO:	Description	Index NO:	Part NO:	Description
1	CF-01	Filter Body	18	CR-05	Spring	35	CR-21	Spring Socket	52	BL-17	Adjusting Ring
2	CF-02	O-Ring	19	CR-06	Anchor Ring	36	CL-01	Lubricator Body	53	BL-18	O-Ring
3	CF-03	Spiral Baffle	20	CR-07	E-Ring	37	CL-02	Distance Piece	54	BL-19	Drip pipe
4	CF-04	Filter Element	21	CR-08	Regulating Nut	38	CL-03	Packing	55	BL-20	O-Ring
5	CF-05	Umbrella Baffle	22	CR-09	Governor Spinlle	39	BL-04	O-Ring	56	BL-21	Visi-Dome
6	BF-06	Drain Cap	23	CR-10	Governor Socket	40	CL-05	Distance Block	57	BL-22	O-Ring
7	BF-07	Drain Nut	24	CR-11	Push Button	41	BL-06	O-Ring	58	BL-23	Filling plug
8	BF-08	Drain Screw	25	CR-12	Pressure Governor	42	BL-07	Filter Leaf	59	BL-25	Spring
9	CF-09	Plastic Bowl	26	BR-13	O-Ring	43	BL-08	Ball Steel	60	BL-26	O-Ring
10	CF-10	Bowl Guard	27	CR-14	Spool	44	BL-09	O-Ring	61	BL-27	EnJector Pin
11	BF-11	Push Button Key	28	CR-15	Spring Pressure Plug	45	CL-10	Governor	62	CF-10	Bowl Guard
12	BF-13	Rubber	29	CR-16	O-Ring	46	BL-11	Spring	63	CF-11	Push Button
13	BF-16	Locking Ring	30	CR-17	Spring	47	BL-12	Slack Adjustor	64	CFC-01	Mounting Bracket
14	CR-01	Regulator Body	31	CR-18	O-Ring	48	CL-13	Setting up piece	65	CFC-02	Anchor Block
15	CR-02	Exhaust Nozzle	32	CR-19	Valve Cap	49	CL-14	Screw	66	CFC-03	Screw
16	CR-03	Pressure Packing	33	BR-20	Screw	50	CL-15	Tube	67	CFC-04	Packing
17	CR-04	Plastic Ring	34	PG-20	Pressure Gauge	51	CL-16	Plastic Bowl	68		

# C系列-爆炸圖

二點式組合



Index NO:	Part NO:	Description
1	CFR-01	Filter Regulator Body
2	CF-02	O-Ring
3	CF-03	Spiral Baffle
4	CF-04	Filter Element
5	CF-05	Umbrella Baffle
6	BF-06	Drain Cap
7	BF-07	Drain Nut
8	BF-08	Drain Screw
9	CF-09	Plastic Bowl
10	CF-10	Bowl Guard
11	BF-11	Push Button Key
12	BF-13	Rubber
13	BF-16	Locking Ring
14	CR-02	Exhaust Nozzle
15	CR-03	Pressure Packing
16	CR-04	Plastic Ring
17	CR-05	Spring
18	CR-06	Anchor Ring
19	CR-07	E-Ring
20	CR-08	Regulating Nut
21	CR-09	Governor Spindle
22	CR-10	Governor Socket
23	CR-11	Push Button
24	CR-12	Pressure Governor
25	BR-13	O-Ring
26	CR-14	Spool
27	CR-15	Pressure Plug
28	CR-16	O-Ring
29	CR-17	Spring
30	BR-20	Screw/PT1/4
31	PG-20	Pressure Gauge
32	CR-21	Spring Socket
33	CL-01	Lubricator Body
34	CL-02	Distance Place
35	CL-03	Packing
36	BL-04	O-Ring
37	CL-05	Distance Block
38	CL-06	O-Ring
39	BL-07	Filter Leaf
40	BL-08	Ball Steel
41	BL-09	O-Ring
42	CL-10	Governor
43	BL-11	Spring
44	BL-12	Stack Adjustor
45	CL-13	Setting up plate
46	CL-14	Screw
47	CL-15	Tul e
48	CL-16	Plastic Bowl
49	BL-17	Adjusting Ring
50	BL-18	O-Ring
51	BL-19	Drip pipe
52	BL-20	O-Ring
53	BL-21	Visi-Dome
54	BL-22	O-Ring
55	BL-23	Filling plug
56	BL-25	Sping
57	BL-26	O-Ring
58	BL-27	EnJeter Pin
59	CFC-01	Mounting Bracket
60	CFC-02	Anchor Block
61	CFC-03	Screw
61	CFC-04	Packing