


N200系列-爆炸圖


三點式組合



Index No:	Part No:	Description	Price	Index No:	Part No:	Description	Price	Index No:	Part No:	Description	Price
1	NF20-01	Filter Body		23	AR-03	Spring		45	AL-04	Screw	
2	AF-02	O-Ring		24	AR-08	O-Ring		46	AL-02	Tube	
3	AF-03	Spiral Baffle		25	AR-07	Valve Cap		47	AL-06	Plastic Bowl	
4	AF-04	Filter Element		26	NBR-15	Pressure Gauge cover		48	BL-17	Adjusting Ring	
5	AF-05	Umbrella Baffle		27	NBR-16	Screw		49	BL-18	O-Ring	
6	AF-06	Plastic Bowl		28	PG-22N	Pressure Gauge		50	BL-19	Drip pipe	
7	AF-09	Valve Cores		29	NBR-17	Screw		51	BL-20	O-Ring	
8	NR20-01	Regulator Body		30	NBR-18	O-Ring		52	BL-21	Visi-Dome	
9	AR-02	Exhaust Nozzle		31	NL20-01	Lubricator Body		53	AL-03	Filling plug	
10	AR-05	Bush		32	AF-02	O-Ring		54	AL-05	O-Ring	
11	AR-06	O-Ring		33	BL-02	Distance Piece		55	BL-25	Spring	
12	BR-03	Pressure Packing		34	BL-03	Packing		56	BL-26	O-Ring	
13	BR-04	Plastic Ring		35	BL-04	O-Ring		57	BL-27	Enjeter Pin	
14	BR-05	Spring		36	BL-05	Distance Block		58	N20-D1	Mounting Bracket	
15	BR-07	E-Ring		37	BL-06	O-Ring		59	N20-D2	Anchor Block	
16	BR-08	Regulating Nut		38	BL-07	Filter Leaf		60	BC-03	Screw	
17	BR-09	Governor Spindle		39	BL-08	Ball Steel		61	AC-04	Packing	
18	BR-10A	Governor Socket		40	BL-09	O-Ring					
19	BR-11A	Push Button		41	BL-10	Governor					
20	BR-12A	Pressure Governor		42	BL-11	Spring					
21	BR-06B	Anchor Ring		43	BL-12	Slack Adjustor					
22	NFR20-03	Spool		44	BL-13	Setting up piece					

N200系列-爆炸圖

二點式組合



Index No:	Part No:	Description	Price
1	NFR20-01	Filter Regulator Body	
2	NFR20-03	Spool	
3	AF-02	O-Ring	
4	AF-03	Spiral Baffle	
5	AR-03	Spring	
6	AF-04	Filter Element	
7	AF-05	Umbrella Baffle	
8	AF-06	Plastic Bowl	
9	AF-09	Valve Cores	
10	AFR-02	Exhaust Nozzle	
11	AR-05	Bush	
12	AR-06	O-Ring	
13	BR-03	Pressure Packing	
14	BR-04	Plastic Ring	
15	BR-05	Spring	
16	BR-07	E-Ring	
17	BR-08	Regulating Nut	
18	BR-09	Governor Spindle	
19	BR-10A	Governor Socket	
20	BR-11A	Push Button	
21	BR-12A	Pressure Governor	
22	BR-06B	Anchor Ring	
23	NBR-15	Pressure Gauge cover	
24	NBR-16	Screw	
25	PG-22N	Pressure Gauge	
26	NBR-17	Screw	
27	NBR-18	O-Ring	
28	NL20-01	Lubricator Body	
29	AF-02	O-Ring	
30	BL-02	Distance Piece	
31	BL-03	Packing	
32	BL-04	□-Ring	
33	BL-05	Distance Block	
34	BL-06	□-Ring	
35	BL-07	Filter Leaf	
36	BL-08	Ball Steel	
37	BL-09	□-Ring	
38	BL-10	Governor	
39	BL-11	Spring	
40	BL-12	Slack Adjustor	
41	BL-13	Setting up piece	
42	AL-04	Screw	
43	AL-02	Tube	
44	AL-06	Plastic Bowl	
45	BL-17	Adjusting Ring	
46	BL-18	□-Ring	
47	BL-19	Drip pipe	
48	BL-20	□-Ring	
49	BL-21	Visi-Dome	
50	AL-03	Filling plug	
51	AL-05	O-Ring	
52	BL-25	Spring	
53	BL-26	O-Ring	
54	BL-27	Enjetor Pin	
55	N20-D1	Mounting Bracket	
56	N20-D2	Anchor Block	
57	BC-03	Screw	
58	AC-04	Packing	