


N400系列-爆炸圖


三點式組合



Index NO:	Part NO:	Description	Index NO:	Part NO:	Description	Index NO:	Part NO:	Description	Index NO:	Part NO:	Description
1	NBF-01	Filter Body	18	NBR-05	Spring	35	PG-22N	Pressure Gauge	52	BL-06	Plastic Bowl
2	BF-02	O-Ring	19	NBR-06	Anchor Ring	36	NBR-17	Screw	53	BL-17	Adjusting Ring
3	BF-03	Spiral Baffle	20	BR-07	E-Ring	37	NBL-01	Lubricator Body	54	BL-18	□-Ring
4	BF-04	Filter Element	21	NBR-08	Regulating Nut	38	NBL-02	Distance Piece	55	BL-19	Drip pipe
5	BF-05	Umbrella Baffle	22	NBR-09	Governor Spindle	39	BL-03	Packing	56	BL-20	□-Ring
6	BF-06	Drain Cap	23	NBR-10	Governor Socket	40	BL-04	□-Ring	57	BL-21	Visi-Dome
7	BF-07	Drain Nut	24	BR-11	Push Button	41	BL-05	Distance Block	58	NBL-22	□-Ring
8	BF-08	Drain Screw	25	NBR-12	Pressure Governor	42	BL-06	□-Ring	59	BL-23	Filling plug
9	BF-09	Plastic Bowl	26	BR-13	□-Ring	43	BL-07	Filter Leaf	60		
10	NBF-10	Bowl Guard	27	NBR-14	Spool	44	BL-08	Ball Steel	61	BL-25	Spring
11	NBF-11	Push Button Key	28	BR-15	Spring Pressure Plug	45	BL-09	□-Ring	62	BL-26	O-Ring
12	BF-13	Rubber	29	BR-16	O-Ring	46	BL-10	Governor	63	BL-27	Enjeter Pin
13	BF-16	Locking Ring	30	BR-17	Spring	47	BL-11	Spring	64	N-40D	Mounting Bracket
14	NBR-01	Regulator Body	31	BR-18	O-Ring	48	BL-12	Slack Adjustor	65	NBC-01	Anchor Block
15	BR-02	Exhaust Nozzle	32	BR-19	Valve Cap	49	BL-13	Setting up piece	66	NBC-03	Screw
16	NBR-03	Pressure Packing	33	NBR-15	Pressure Gauge cover	50	BL-14	Screw	67		
17	NBR-04	Plastic Ring	34	NBR-16	Screw	51	BL-15	Tube	68		

N400系列-爆炸圖

二點式組合



Index NO:	Part NO:	Description
1	NBFR-01	Filter Regulator Body
2	BF-02	O-Ring
3	BF-03	Spiral Baffle
4	BF-04	Filter Element
5	BF-05	Umbrella Baffle
6	BF-06	Drain Cap
7	BF-07	Drain Nut
8	BF-08	Drain Screw
9	BF-09	Plastic Bowl
10	NBF-10	Bowl Guard
11	NBF-11	Push Button Key
12	BF-13	Rubber
13	BF-16	Locking Ring
14	BR-02	Exhaust Nozzle
15	NBR-03	Pressure Packing
16	NBR-04	Plastic Ring
17	NBR-05	Spring
18	NBR-06	Anchor Ring
19	BR-07	E-Ring
20	NBR-08	Regulating Nut
21	NBR-09	Governor Spindle
22	NBR-10	Governor Socket
23	BR-11	Push Button
24	NBR-12	Pressure Governor
25	BR-13	O-Ring
26	NBR-14	Spool
27	BR-15	Spring Pressure Plug
28	BR-16	O-Ring
29	BR-17	Spring
30	NBR-15	Pressure Gauge cover
31	NBR-16	Screw
32	PG-22N	Pressure Gauge
33	NBR-17	Screw
34	NBL-01	Lubricator Body
35	BL-02	Distance Piece
36	BL-03	Packing
37	BL-04	O-Ring
38	BL-05	Distance Block
39	BL-06	O-Ring
40	BL-07	Filter Leaf
41	BL-08	Ball Steel
42	BL-09	O-Ring
43	BL-10	Governor
44	BL-11	Spring
45	BL-12	Stack Adjustor
46	BL-13	Setting up piece
47	BL-14	Screw
48	BL-15	Tube
49	BL-16	Plastic Bowl
50	BL-17	Adjusting Ring
51	BL-18	O-Ring
52	BL-19	Drip pipe
53	BL-20	O-Ring
54	BL-21	Visi-Dome
55	BL-22	O-Ring
56	BL-23	Filling plug
57	BL-25	Spring
58	BL-26	O-Ring
59	BL-27	Enjetor Pin
60	N-40D	Mounting Bracket
61	N-40D	Anchor Block
62	NBC-01	Packing
63	NBC-03	Screw