



UFC400-W series 1/4",3/8",1/2" AIR CONTROL UNIT

UFC400-W series 1/4",3/8",1/2" AIR CONTROL UNIT



UFC400-W series F.R.L PARTS LIST

Index No.	Part No.	Description	Price	Index No.	Part No.	Description	Price	Index No.	Part No.	Description	Price
1	UFR400-01	Pressure Governor		16	UFR400-12	Pressure Gauge cover		31	N300-02	Rubber	
2	UFR400-02	Identification Color Ring		17	BF-05	Exhaust pipe		32	BF-13	O-Ring	
3	UFR400-03	Anchor Ring		18	BF-06	O-Ring		33	UFR400-18	Plastic Bowl	
4	BF-01	Screw		19	BF-07	Pressure gauge cover plate		34	UFR400-19	Bowl Guard	
5	UFR400-04	Governor Socket		20	BF-08	Screw		35	UFR400-20	Spring	
6	BF-02	O-Ring		21	BF-09	O-Ring		36	UFR400-21	Push Button Key	
7	UFR400-05	Governor Spindle		22	PG-22N	Pressure gauge		37	N300-03	Side exhaust body	
8	UFR400-06	Regulating Nut		23	BF-10	Screw		38	N300-04	Fixed block	
9	UFR400-07	Spring		24	UFR400-13	Pressure plug ring		39	BF14	O-Ring	
10	UFR400-08	Exhaust Nozzle		25	BF-11	O-Ring		40	N300-05	Spring	
11	BF-03	O-Ring		26	UFR400-14	Pressure plug spring		41	BF15	O-Ring	
12	BF-04	O-Ring		27	UFR400-15	Solenoid Valve		42	BF16	O-Ring	
13	UFR400-09	O-Ring		28	UFR400-16	Filter Element		43	N300-06	Actuating rod	
14	UFR400-10	Spool		29	UFR400-17	Umbrella Valve					
15	UFR400-11	Regulator Body		30	N300-01	Drain Cap					



UFC400-W series F.R.L PARTS LIST

Index No.	Part No.	Description	Price
1	UFR400-22	Fixed block	
2	UFR400-23	Fixed seal	
3	BF-12	Screw	
4	UL400-01	Valve Dome	
5	BF-17	O-Ring	
6	UL400-02	Screw	
7	UL400-03	Base	
8	BF-18	O-Ring	
9	BF-19	O-Ring	
10	UL400-04	Drip pipe	
11	BF-20	O-Ring	
12	UL400-05	Filling plug	
13	BF-21	O-Ring	
14	UL400-06	Lubricator Body	
15	UL400-07	Lubricator Outer cover	
16	UL400-08	Packing	
17	BF-22	Ball Seat	
18	BF-23	O-Ring	
19	BF-24	Ball Seat	
20	BF-25	Spring	
21	BF-26	O-Ring	
22	UL400-09	Distance Piece	
23	UL400-10	Distance Block	
24	UL400-11	Regulator balls	
25	BF-27	Screw	
26	BF-28	O-Ring	
27	UL400-12	Plastic Bowl	